MQ-4 MODULE



MQ-4 Module is used in gas leakage detecting equipment in family and industry, are suitable for detecting of CH4 ,Natural gas,LNG. Avoid the noise of alcohol and cooking fumes and cigarette smoke. The module gives out the concentration of the gases as a analog voltage equivalent to the concentration of the gases. The module also has a on-board comparator for comparing against a adjustable preset value and giving out a digital high or low.

Description

Specifications

- Voltage: 5V
- Detecting concentration :200-10000ppm Methane (CH4)
- Analog and Digital Output
- Digital Out is High or Low based on a adjustable preset threshold.